




Standard Duty Rear Blade

BRB-200 Series



Operator's Manual

Page left blank intentionally

TO THE DEALER:

Assembly and proper installation of this product is the responsibility of the Tar River dealer. Read manual instructions and safety rules. Make sure all items on the Dealer's Pre-Delivery and Delivery Check Lists in the Owner's/Operator's Manual are completed before releasing equipment to the owner.

TO THE OWNER:

Read this manual before operating your Tar River equipment. The information presented will prepare you to do a better and safer job. Keep this manual handy for ready reference. Require all operators to read this manual carefully and become acquainted with all the adjustment and operating procedures before attempting to operate. Replacement manuals can be obtained from your selling dealer. The equipment you have purchased has been carefully engineered and manufactured to provide dependable and satisfactory use. Like all mechanical products, it will require cleaning and upkeep. Lubricate the unit as specified. Observe all safety information in this manual and safety decals on the equipment. For service, your authorized Tar River dealer has trained mechanics, genuine Tar River service parts, and the necessary tools and equipment to handle all your needs. Use only genuine Tar River service parts. Substitute parts will void the warranty and may not meet standards required for safe and satisfactory operation.

Record your implement model and serial number in the space provide below. Your dealer will need this information to give you prompt, efficient service.

Model Number: _____

Serial Number: _____

Date Purchased: _____

Table of Contents

Introduction	5
Technical Specifications	5
Safety	6
Safety Signal Words	6
General Safety Guidelines	7
Safety Decal Care	7
Before Operation	8
During Operation	9
Highway And Transport Operations	10
Assembly	12
Attaching to tractor	13
Operating Instructions.....	14-15
Lubrication and Maintenance	16
Torque Specifications	17
Parts Breakdown	20-21
Warranty	22

Table of Contents

Introduction

Thank you for purchasing your Standard Duty Rear Blade. The BRB-200 Series Rear Blades are the perfect choice for landscaping, leveling, grading and backfilling. The BRB-200 Series Rear Blades are an excellent choice for your compact tractor.

Technical Specifications

- Suitable for landscaping, leveling, grading and backfilling.
- Suitable for nurseries, small farms, home sites.
- Suitable for maintaining gravel, dirt driveways

	BRB-205	BRB-206	BRB-207
Max. HP	40	40	40
Working width	60"	72"	84"
Moldboard height	14"	14"	14"
Moldboard thickness	1/4"	1/4"	1/4"
Moldboard angle & tilt	Yes	Yes	Yes
Weight lbs.	190	216	243

Important Safety Information

Safety

It is important that you read the entire manual and to become familiar with this product before you begin using it. This product is designed for certain applications only. The manufacturer cannot be responsible for issues arising from modification. We strongly recommend this product not be modified and /or used for any application other than that for which it is designed. If you have any questions relative to a particular application, DO NOT use the product until you have first contacted us to determine if it can or should be performed on the product.

Read and understand this manual and all safety signs before operating and maintaining . Review the safety instructions and precautions annually.

Safety Signal Words

TAKE NOTE! This safety alert symbol found though out this manual is used to call you attention to instructions involving you personal safety and the safety of others. Failure to follow these instructions can result in injury or death.



**This symbol means:
Attention!
Become alert!
Your safety is involved!**

Note the use of the signal words, DANGER, WARNING and CAUTION with the safety messages. The appropriate signal word for each has been selected using the following guidelines:



DANGER: Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. This signal word is to be limited to the most extreme situations typically for machine components which, for functional purposes, cannot be guarded.



WARNING: Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury, and includes hazards that are exposed when guards are removed. It may also be used to alert against unsafe practices.



CAUTION: Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

Important Safety Information

General Safety Guidelines

The safety of the operator is one of the main concerns in designing and developing a new piece of equipment. Designers and manufacturers build in as many safety features as possible. However, every year many accidents occur which could have been avoided by a few seconds of thought and a more careful approach to handling equipment. You, the operator, can avoid many accidents by observing the following precautions in this section. To avoid personal injury, study the following precautions and insist those working with you, or for you, follow them.

Replace any DANGER, WARNING, CAUTION or instruction safety decal that is not readable or is missing. Location of such decals are indicated in this manual. Do not attempt to operate this equipment under the influence of drugs or alcohol.

Review the safety instructions with all users annually.

This equipment is dangerous to children and persons unfamiliar with its operation. The operator should be a responsible adult familiar with farm machinery and trained in this equipment's operations. **Do not allow persons to operate or assemble this unit until they have read this manual and have developed a thorough understanding of the safety precautions and of how it works.**

To prevent injury of death, use a tractor equipped with a Roll Over Protection System (ROPS). Do not paint over, remove or deface any signs or warning decals on your equipment. Observe all safety signs and practice the instructions on them.

Never exceed the limits of a piece of machinery. If its ability to do a job, or to do so safely, is in question - **Don't try it!**



Safety Decal Care

- Keep safety signs clean and legible at all times.
- Replace safety signs that are missing or have become illegible.
- Replaced parts that displayed a safety sign should also display the current safety sign
- Safety signs are available from your Distributor or Dealer Parts Department or the factory.

Important Safety Information

How to install Safety Signs:

- Be sure that the installation area is clean and dry.
- Decide on the exact position before you remove the backing paper.
- Remove the smallest portion of the split backing paper.
- Align the decal over the specified area and carefully press the small portion with the exposed sticky backing in place.
- Slowly peel back the remaining paper and carefully smooth the remaining portion of the decal in place.
- Small air pockets can be pierced with a pin and smoothed out using the piece of decal backing paper.



Before Operation

- Carefully study and understand this manual.
- Do not wear loose-fitting clothing, which may catch in moving parts.
- Always wear protective clothing and substantial shoes.
- Assure that all tires are inflated evenly.
- Give the unit a visual inspection for any loose bolts, worn parts or cracked welds, and make necessary repairs. Follow the maintenance safety instructions included with this manual.
- Be sure that there are no tools lying on or in the equipment.
- Do not use the unit until you are sure that the area is clear, especially of children and animals.
- Don't hurry the learning process or take the unit for granted. Ease into it and become familiar with your new equipment.
- Practice operation of your equipment and its attachments. Completely familiarize yourself and other operators with its operation before using.
- Use a tractor equipped with a Roll Over Protection System (ROPS) and fasten your seat belt prior to starting engine.
- The manufacturer does not recommend usage of tractor with ROPS removed.
- Move tractor wheels to the widest recommended settings to increase stability.
- Securely attach to towing unit. Use a high strength, appropriately sized hitch pin with a mechanical retainer and attach safety chain.
- Do not allow anyone to stand between the tongue or hitch and the towing vehicle when backing up to the equipment.
- Do not use the unit until you are sure that the area is clear, especially of children and animals.

Important Safety Information



During Operation

- Children should not be allowed on the product.
- Clear the area of small children and bystanders before moving the feeder.
- If using a towing unit, securely attach feeder by using a hardened 3/4" pin, a metal retainer, and safety chains if required. Shift towing unit to a lower gear before going down steep downgrades, thus using the engine as a retarding force. Keep towing vehicle in gear at all times. Slow down for corners and rough terrain.
- Make sure you are in compliance with all local and state regulations regarding transporting equipment on public roads and highways. Lights and slow moving signs must be clean and visible by overtaking or oncoming traffic when feeder is transported.
- Beware of bystanders, **particularly children!** Always look around to make sure that it is safe to start the engine of the towing vehicle or move the unit. This is particularly important with higher noise levels and quiet cabs, as you may not hear people shouting.
- **NO PASSENGERS ALLOWED!** Do not carry passengers anywhere on, or in, the tractor or equipment, except as required for operation.
- Keep hands and clothing clear of moving parts.
- Do not clean, lubricate or adjust your equipment while it is moving.
- When halting operation, even periodically, set the tractor or towing vehicle brakes, disengage the PTO, shut off the engine and **remove the ignition key.**
- Be especially observant of the operating area and terrain. Watch for holes, rocks or hidden hazards. Always inspect the area prior to operation.
- **DO NOT** operate near the edge of drop-offs or banks.
- **DO NOT** operate on steep slopes as overturns may result.
- Operate up and down (not across) intermediate slopes. Avoid sudden starts and stops.

Important Safety Information



Highway and Transport Operations

- Adopt safe driving practices.
- Keep the brake pedals latched together at all times. **Never use independent braking with machine in tow as loss of control and/or upset of unit can result.**
- Always drive at a safe speed relative to local conditions and ensure that your speed is low enough for an emergency stop to be safe and secure. Keep speed at a minimum.
- Reduce speed prior to turns to avoid the risk of overturning.
- Avoid sudden uphill turns on steep slopes.
- Always keep the tractor or towing vehicle in gear to provide engine braking when going downhill. Do not coast.
- Do not drink and drive!
- Comply with state and local laws governing highway safety and movement of farm machinery on public roads.
- Use approved accessory lighting flags and necessary warning devices to protect operators of other vehicles on the highway during daylight and nighttime transport. Various safety lights and devices are available from your dealer.
- The use of flashing amber lights is acceptable in most localities. However, some localities prohibit their use. Local laws should be checked for all highway and marking requirements.
- When driving the tractor and equipment on the road or highway under 40 kph (20 mph) at night or during the day, use the amber warning lights and a slow moving vehicle (SMV) identification emblem.
- Plan your route to avoid heavy traffic.
- Be a safe and courteous driver. Always yield to oncoming traffic in all situations, including narrow bridges, intersections, etc.
- Be observant of bridge loading ratings. Do not cross bridges rated at lower than the gross weight at which you are operating.
- Watch for obstructions overhead and to the side while transporting.
- Always operate in a position to provide maximum visibility at all times. Make allowances for increased length and weight of the equipment when making turns, stopping the unit, etc.
- Pick the most level route when transporting across fields. Avoid the edges of ditches or gullies and steep hillsides.
- Be extra careful when working in inclines.

Important Safety Information



Highway and Transport Operations

- Maneuver the tractor or towing vehicle at safe speeds.
- Avoid overhead wires or other obstacles. Contact with overhead lines could cause serious injury or death.
- Avoid loose fill, rocks and holes, they can be dangerous for equipment operation or movement.
- Allow for unit length when making turns,
- Operate the towing vehicle from the operator's seat only.
- Never stand alongside of unit with engine running or attempt to start engine and/or operate machine while standing alongside of unit.
- Never leave running equipment attachments unattended.
- As a precaution, always recheck the hardware on equipment following every 100 hours of operation.
Correct all problems. Follow the maintenance safety procedures.

Assembly

- Step 1. Attach the Cutting Edge to the Moldboard. Refer to page 21 in “Parts Section” for part numbers and descriptions of parts and hardware. Be sure to secure the Moldboard with blocks or stands to prevent it from falling over. Make sure that the threaded rod on the Pivot Assembly is pointing up.
- Step 2. Attach the Pivot Assembly to the Moldboard. **NOTE:** A reinforcement plate is welded to one side of the Pivot Assembly. This plate must face **AWAY** from the moldboard when installing, See Fig. 2. **Failure to do so may result in damage to the Pivot Assembly!**
- Step 3. Assemble the 3-Point hitch and attach to the Pivot Assembly.

NOTE: Tighten all hardware to proper torque settings. See “Torque Specifications” chart on page 17.




Fig. 1

Reinforcement Plate (NOTE: Viewed from the back of the Rear Blade)




Fig. 2

Assembly



Danger: When attaching the Rear Blade, *Never* allow anyone to stand between the Rear Blade and the tractor. Serious injury or death can occur!

Attaching the Rear Blade:

- Back up the tractor to the rear blade, while lining up the lower tractor links to the Rear Blade lowers pins.
- Stop the engine, set the brake and remove the key from the tractor.
- Secure the lower tractor arms to the Rear Blade lower pins with lynch pins.
- Raise the Rear Blade Stand and secure with the spring pin.
- Attach the tractor top link to the Rear Blade with the Top Link Pin and r-clip.
- Adjust the tractor sway bars/chains to center the Rear Blade and remove excess sway.
- Adjust lower links and top link so that the Rear Blade is level.
- Operate the tractor hydraulic controls very slowly up and down. There should be no contact between the Rear Blade or any part of the tractor. Failure to check clearance can result in damage to the Rear Blade, tractor (especially the tires) and possible injury to the operator. Maintain no less than 6” of clearance between the Rear Blade, tractor and tractor tires throughout the complete range of motion.




Fig. 3



Danger: Always shut off the tractor engine, set the park brake and remove the key before attaching or servicing the Rear Blade.

Operating Instructions

Angling Adjustment - Forward or Reverse:

The BRB Standard Duty can be rotated 360 degrees and locked in 10 positions (5 forward, 5 reverse), See Fig. 4. The Rear Blade can be rotated on most tractors without removing depending on the width of the rear blade and tractor size.

To adjust blade angle:

1. Lift the Rear Blade off the ground. Take precautions when lifting the rear blade. Keep hands and feet away from under the attachment to prevent injury.
2. It may be necessary to loosen the castle nut holding the Pivot Assembly. Remove the cotter pin from the castle nut and loosen the castle nut. See Fig 5.

Note: Loosen the castle nut only! Do not remove!

3. Remove the pin and r-clip from the Pivot Assembly, See Fig 5.
4. Set the blade at the desired angle and replace the pin and r-clip.
5. Tighten the castle nut and re-insert the cotter pin.








Fig. 5



0 Degree Angle



15 Degree Angle



30 Degree Angle




Fig. 4

Operating Instructions

Tilt Adjustment:

The BRB Standard Duty has three tilt positions, 0 degrees, 15 degrees left or 15 degrees right.

To adjust blade tilt:

1. Lift the Rear Blade off the ground. Take precautions when lifting the rear blade. Keep hands and feet away from under the attachment.
2. It may be necessary to loosen the castle nut. Remove the cotter pin from the castle nut and loosen the castle nut. See Fig 6. **Note: Loosen the nut only! Do not remove!**
3. Remove the pin and r-clip from the rear Pivot Assembly.
4. Set the blade at the desired tilt and replace the pin and r-clip.
5. Tighten the castle nut and re-insert the cotter pin.







Fig. 6



0 Degree Angle



15 Degree Tilt - Left



15 Degree Tilt - Right

Fig. 7

Lubrication & Maintenance

Lubrication and Maintenance.

1. Thoroughly clean the Rear Blade after use.
2. Lubricate moving parts as needed.
3. Store in a shed or under a shelter after use.

1 Hour Check all fasteners and hardware including and retighten as necessary.

As needed: Remove any crop residue, grasses, weeds, or debris wrapped around the rear blade.

Service.

1. Inspect machines overall condition before and after each use.
2. Replace damaged or worn parts with OEM parts.
3. Remove any wrapping, weeds, stalks, trash, ect.

Torque Specifications

Torque Specifications for Common Bolt Sizes															
Inches		Bolt Head Identification						Metric		Bolt Head Identification					
										5.8		8.8		10.9	
Bolt size (inches)	Thread pitch	Grade 2		Grade 5		Grade 8		Class 5.8		Class 8.8		Class 10.9			
		N.m	ft-lb	N.m	ft-lb	N.m	ft-lb	N.m	ft-lb	N.m	ft-lb	N.m	ft-lb		
1/4"	20	7	5	11	8	16	12	M5	0.08	4	3	6	4	9	7
1/4"	28	8	6	13	10	19	14	M6	1	6	4	10	7	15	11
5/16"	18	15	11	24	17	33	25	M8	1.25	16	12	25	18	36	27
5/16"	24	17	13	26	19	37	27	M8	1	17	13	26	19	38	28
3/8"	16	27	20	42	31	59	44	M10	1.5	31	23	48	35	71	52
3/8"	24	31	23	47	35	67	49	M10	1.25	33	24	51	38	75	55
7/16"	14	43	32	67	49	95	70	M10	1	35	26	53	39	78	58
7/16"	20	48	36	75	55	106	78	M12	1.75	54	40	84	62	123	91
1/2"	13	66	48	102	75	144	106	M12	1.5	56	41	87	64	128	94
1/2"	20	75	55	115	85	163	120	M12	1.25	59	44	90	66	133	98
9/16"	12	95	70	147	109	208	154	M14	2	84	62	133	98	195	144
9/16"	18	106	79	164	121	232	171	M14	1.5	94	69	142	105	209	154
5/8"	11	132	97	203	150	287	212	M16	2	131	97	206	152	302	223
5/8"	18	149	110	230	170	325	240	M16	1.5	141	104	218	161	320	236
3/4"	10	233	172	361	266	509	376	M18	2.5	181	133	295	218	421	310
3/4"	16	261	192	403	297	569	420	M18	2	196	145	311	229	443	327
7/8"	9	226	167	582	430	822	606	M18	1.5	203	150	327	241	465	343
7/8"	14	249	184	642	473	906	668	M20	2.5	256	189	415	306	592	437
1"	8	339	250	873	644	1232	909	M20	1.5	288	212	454	335	646	476
1"	12	371	273	955	704	1348	995	M22	2.5	344	254	567	418	807	595
1-1/8"	7	480	354	1077	794	1746	1288	M22	1.5	381	281	613	452	873	644
1-1/8"	12	539	397	1208	891	1958	1445	M24	3	444	327	714	526	1017	750
1-1/4"	7	677	500	1519	1120	2463	1817	M24	2	488	360	769	567	1095	808
1-1/4"	12	750	553	1682	1241	2728	2012	M27	3	656	484	1050	774	1496	1103
1-3/8"	6	888	655	1992	1469	3230	2382	M27	2	719	530	1119	825	1594	1176
1-3/8"	12	1011	746	2268	1673	3677	2712	M30	3.5	906	668	1420	1047	2033	1499
1-1/2"	6	1179	869	2643	1949	4286	3161	M30	2	1000	738	1600	1180	2250	1659
1-1/2"	12	1326	978	2974	2194	4823	3557	M36	4	1534	1131	2482	1830	3535	2607

Notes:

This chart is an approximate estimate of torque values.

Always tighten hardware to these values unless a different torque value or tightening procedure is listed for a specific application.

Fasteners must always be replaced with the same grade as specified in the manual.

Always use the proper tool for tightening hardware: SAE for SAE hardware and Metric for Metric hardware.


Make sure that fastener threads are clean and that you properly start thread engagement.

Page left blank intentionally




Standard Duty Rear Blade

BRB-200 Series



Part's Manual

BRB-2 Rear Blade Assembly



BRB-2 Rear Blade Assembly

Item	Part #	Description	Qty.
1	GB180017	Main frame	1
2	GB180020	A-frame straps	2
3	GB180006	Swivel	1
4	GB180023-60	Moldboard 60"	1
	GB180023-72	Moldboard 72"	1
	GB180023-84	Moldboard 84"	1
5	RB10028-60	Cutting edge 60"	1
	RB10028-72	Cutting edge 72"	1
	RB10028-84	Cutting edge 84"	1
6	GB180012	Brace	1
7	GB180024	Stand	1
8	GB180010	Pin M18 x 150	1
9	RC4	R clip M4	3
10	GB180018	Pin M19 x 95	1
11	BM1620100	Bolt HH M16-2.0 x 100	1
12	GB180019	Hitch pin	2
13	BM162055	Bolt HH M16-2.0 x 55	1
14	GB180016	Steel collar	2
15	CP5x50	Cotter pin M5 x 50	2
16	LNM273	Nut castle M27-3.0	2
17	LW22	Washer flat M22	2
18	NM2225	Nut M22-2.5	2
19	FW16	Washer flat M16	-
20	LW16	Washer lock M16	-
21	NM1620	Nut HH M16-2.0	-
22	CBM162040	Bolt carriage M16-2.0 x 40	-
23	LYNPN06	Lynch pin M6	1
24	GB180009	Pin M18 x 120	1

Warranty

LIMITED WARRANTY

Belco Resources Equipment warrants to the original purchaser of any new piece of machinery from Belco Resources Equipment, purchased from an authorized Belco Resources Equipment dealer, that the equipment be free from defects in material and workmanship for a period of one (1) year for non-commercial, state, and municipalities' use, ninety (90) days for commercial use from date of retail sale. Warranty for rental purposes is thirty (30) days. The obligation of Belco Resources Equipment to the purchaser under this warranty is limited to the repair or replacement of defective parts.

Replacement or repair parts installed in the equipment covered by this limited warranty are warranted for ninety (90) days from the date of purchase of such part or to the expiration of the applicable new equipment warranty period, whichever occurs later. Warranted parts shall be provided at no cost to the user at an authorized Belco Resources Equipment dealer during regular working hours. Belco Resources Equipment reserves the right to inspect any equipment or parts, which are claimed to have been defective in material or workmanship.

This limited warranty does not apply to and excludes wear items such as shear pins, tires, tubes knives, blades or other wear items. Oil or grease is not covered by this warranty.

All obligations of Belco Resources Equipment under this limited warranty shall be terminated if:

- Proper service is not performed on the machine.

- The machine is modified or altered in any way.

- The machine is being used or has been used for purposes other than those for which the machine was intended.

DISCLAIMER OF IMPLIED WARRANTIES & CONSEQUENTIAL DAMAGES

Belco Resources Equipment obligation under this limited warranty, to the extent allowed by law, is in lieu of all warranties, implied or expressed, including implied warranties of merchantability and fitness for a particular purpose and any liability for incidental and consequential damages with respect to the sale or use of the items warranted. Such incidental and consequential damages shall include but not be limited to: transportation charges other than normal freight charges; cost of installation other than cost approved by Belco Resources Equipment; duty; taxes; charges for normal service or adjustment; loss of crops or any other loss of income; rental of substitute equipment, expenses due to loss, damage, detention or delay in the delivery.

REGISTRATION

The online Warranty Registration must be completed in order to qualify for coverage on this Limited Warranty. Visit br-equipment.com, click on "Warranty Registration" and completely fill out the form to register the new piece of equipment.

Page left blank intentionally



401 Jeffreys Road
Rocky Mount, NC 27804
www.tarrivermfg.com

Tel: 252-822-7140
Fax: 252-787-5855
Sales@tarrivermfg.com